


- ① GUTTER AND END CAP.
- ② DOWNSPOUT.
- ③ WEATHERPROOF SUPPORT STRAP.
- ④ DOWNSPOUT OUTLET
- ⑤ RAIN BARREL.
- ⑥ MOSQUITO PREVENTION SCREEN (1/16" MESH).
- ⑦ 1-1/4" DIAMETER PVC OR SUMP PUMP HOSE OVERFLOW.
- ⑧ WATER LINE.
- ⑨ SPIGOT TO DRAIN COLLECTED WATER.
- ⑩ 6"-12" ELEVATED FLAT SURFACE.
- ⑪ ROCK LINED AREA @ OVERFLOW.



**NOTES:**

- A. USE APPROVED BARREL. TRASH BINS AND OTHER SIMILAR ITEMS WILL NOT BE ACCEPTED.
- B. THE GUTTER AND DOWNSPOUT MUST BE SECURELY ATTACHED WITH GALVANIZED OR STAINLESS STEEL FASTENERS.
- C. POSITION DOWNSPOUT PROPERLY TO AVOID STANDING WATER.
- D. DRAIN OVERFLOW AWAY FROM HOME, OTHER STRUCTURES AND WALLS. DRAIN TOWARDS LANDSCAPE.
- E. ELEVATE BARREL WITH CMU BLOCK, PAVERS, STONE, CONCRETE, WOOD OR OTHER MATERIAL.
- F. DRAIN BARRELS AFTER EACH RAIN EVENT TO MAXIMIZE RAIN WATER USE FOR YARD.
- G. CONSIDER MATCHING COLORS OF COMPONENTS TO EXISTING SYSTEM AND/ OR ARCHITECTURE.
- H. USE ROCK, SPLASH PAD, PERFORATED PIPE OR DOWNSPOUT EXTENDER AT DISPERSION AREA.

**RAIN BARREL  
W/ OVERFLOW**

**Waterscape Rebate Program  
County of San Diego**

**WRP - 07**